

EZTALK WIRELESS HEADSET

User Manual



Model: MyBat Pro Eztalk

Product Overview:



- Volume Down
 LED Indicator
 Micro USB
- 4. Charging Base Connector5. Multi-Function Button
- 6. Volume Up 7. Microphone

Package Includes:



A.MyBat Pro Eztalk Wireless Headset x 1



B.Charge Base x 1



C.Micro USB Charging Cable x 1



D.User Manual x 1

Basic Operation:

MFB	Power On	Press & Hold Button for 1 to 3 seconds
	Power Off	Press & Hold for 5 seconds
	Pairing Mode	When powered off, press & hold for 5 to 8 seconds. If on and unconnected, double press the button to enter pairing mode.
	Play / Pause	Quickly press button
	Redial a call	Double press the button to dial previous call
	Vvoice Command	Press & Hold for 1 second then release to activate
	Audio Switch	Press & Hold for 1 second to switch between phone and audio functions
	Answer call	Quickly press button when call is incoming
	End Call	Quickly press button during the call
	Reject call	Press & Hold for 1 second when call is incoming
Volume +	Volume Up	Quickly press button
	Next Song	Press & Hold for 1 second
Volume -	Volume Down	Quickly press button
	Previous Song	Press & Hold for 1 second

Button Function Operation Instruction

Bluetooth Pairing and Setup:

- A. When powered off, press & hold for 5 to 8 seconds. If on and unconnected, double press the button to enter pairing mode. LED Indicator light on headset will flash blue and red when in pairing mode.
- B. Turn bluetooth settings on your device and search for "MyBat Pro Eztalk" on list to connect. LED Indicator will flash blue once connected.
- C. Control volume, answer calls, and skip tracks all from the MyBat Pro Eztalk Wireless Headset.

Connect Two Devices:

- A. Follow instructions to pair the first device as noted above. Once connected, turn of the bluetooth
- function for the first device.

 B. Double press the button on Headset to enter pairing mode, check LED Indicator is flashing blue
- C. On the second device, turn the bluetooth settings on and search for "MyBat Pro Eztalk" on list to connect. LED Indicator will flash blue once
- D. Turn the Bluetooth settings back on the first device to reconnect to "MyBat Pro Eztalk" and now both devices will be connected.



Music can only be played from one device, no matter if there are two devices connected. If you would like to play music from the secondary device, the music app and function must be stopped from the first device. The same applies for calls.


Mode	LED Indicator	
Power on	LED Blue flashes 1 second	
Power off	LED Red flashes 1 second	
Pairing mode	LED Red & Blue flashes alternately	
Connected	LED Blue flashes once every 5 seconds	
Charging	Solid LED Red	
Full charged	Solid LED Blue	
Low battery	LED Red flashing	

Please charge the EZTALK Wireless Headset as soon as the LED flashes Red. Charging time is approx. 2 hours. The LED will turn Blue once fully charged. 1. Charge Connections



Charge with Micro USB Cable (*Adapter Sold Separately)

2.Charging Base



Charging with Charge Base

Please place the EZTALK Wireless Headset onto the charging base, then connect the base to the Micro USB cable. *Adapter Sold Separately.

Note: Please charge this headset at least once every two months if not in use. Please charge this headset at least once every two months if not in use.

Bluetooth Version: Bluetooth V5.0 Bluetooth Chipset: CSR 8615 Operation Range: 10M Bluetooth Protocols: HSP HFP A2DP AVRCP CODEC Code: SBC
Battery Capacity: 180maH/3.7V Charging Time: 2H Stand-by Time: 200H Working Time: About 17H (50% Volume) Headset Net Weight: About 51g Charge Base Net Weight: About 242g Headset Dimension: 163.21*142.27*48.5mm Charge Base Dimension: 79*73*31mm

Actual working time wilf vary depending on type

Notice of compliance



operation.

FCC rules
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

including interference that may cause undesired

namful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV

FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter Caution: The user is cautioned that changes or modifications not expressly approved by the party

responsible for compliance could void the user's authority to operate the equipment.

A: My device is no longer connecting to the EZTALK Wireless Headset. How do I reconnect?

The Wireless Headset will automatically try to connect with a device it was successful paired with. If unsuccessful, please disconnect the bluetooth pairing from your device and initiate the pairing process from the beginning.

B. How can I remove a paired device from the EZTALK Wireless Headset?

To remove paired devices, press and hold both Volume Up and Volume Down buttons at the same time for 5 seconds. The LED Indicator will flash Blue and Red which means the pairing has been removed successfully. If there is a pairing connectionproblem, you can try this step to reset

C. What is the password for pairing?

If your device requires a password for pairing, try one of the following options below: 0000, 8888, 1111 or 1234. Note, not all devices require a password to be entered

D. What power source do I need to use to charge the Wireless Headset?

Any standard USB-A compatible adapter or port will allow you to charge the Headset. Please note the adapter or power source is not included, only the Micro USB Cable and Charging Base.

E. How can I enter Three-Way Calling mode?

If a secondary call is incoming, quickly press the Multi-Function Button to answer the new call and hang up the current call. To put your current call on hold, double press the button to answer the new call. To reject an incoming call while on the phone, press and hold the button for 1 second. To switch between calls, quickly double press the button to alternate between callers.

www.P65Warnings.ca.gov Made in China





