




BlockParty Bluetooth Speaker



User Manual

Model: MyBat Pro BlockParty

WELCOME

Thank you for using the MyBat Pro Block Party Bluetooth Speaker. Get ready to cube it up and amplify your party with BlockParty - the speaker that packs a punch with its sleek, cube-shaped design and thumping sound!


Please read this user manual carefully and keep it for future reference.

PACKAGE CONTENTS


1. BlockParty Bluetooth Speaker
2. 3.5 Auxiliary Cable
3. Micro USB Charging Cable
4. User Manual



MyBat Pro BlockParty
Bluetooth Speaker



3.5mm
Auxiliary Cable





Micro USB
Charging Cable





User Manual

PRODUCT OVERVIEW



1. Carrying Strap
2. Built-In Phone Stand
3. Control Panel
4. Bass Diaphragm
5. Party Lights
6. Charging Port
7. Indicator Light
8. Micro SD Slot
9. USB Port
10. Aux Input

CONTROL PANEL



— Volume Down: Press & hold to decrease the volume.
Previous Track: Click 1X to return to previous song.

* Party Lights:
On/Off: Press & Hold
Flashing: Click 1X

+ Volume Up: Press & hold to increase the volume.
Next Track: Click 1X to switch to the next song.

M Mode Button:
Switches between Bluetooth, Aux, USB, Micro SD and FM Radio play modes.


▶ Play/Pause Button:
Play/Pause: Click 1X (While Playing Music)
Answer/End Call: Click 1X (During Incoming Call/On Call)
Search Stations (While in FM Play): Click 1X to start/end the search.

⏻ Power Button:
Power On/Off: Press & hold

CHARGE THE SPEAKER

Fully charge the BlockParty before first use.

NOTE: It takes approximately 3 hours for a full charge.



Connect the USB-A plug to a charger with a 5W power output, and insert the Micro USB plug into the charging port.


POWER ON / OFF

1. Power on: Press and hold "⏻" button for 3 seconds, the speaker will be turned on, and a voice prompt of "Power on" will be issued.

2. Power off: Press and hold "⏻" button for 3 seconds, the speaker will be turned off, and a voice prompt of "Power off" will be issued.

BLUETOOTH PAIRING

1. Turn on the speaker, the speaker will have a voice prompt "Ready to Pair".
2. Ensure your device's Bluetooth setting is turned on.
3. Search for devices and click "MyBat Pro BlockParty" to pair the speaker to your device.
4. Once paired, you will hear a voice prompt of "Paired Successfully."



MUSIC FUNCTION

- ▶ Play / Pause
- + Volume Up / Next Track
- Volume Down / Previous Track

CALL FUNCTION

- ▶ Answer / Hang Up

PLAY MODES

Aux: Use the included 3.5mm auxiliary cable to connect the speaker to your device. Once connected, you will hear a voice prompt of "Line In."

USB: Once you insert your USB Drive into the slot, you will hear a voice prompt of "U Disk" and your music will begin to play.

FM Radio: Press the M button to use the built-in FM Radio. You will hear a voice prompt of "FM Tuner" once entering the mode.

NOTE: We recommend plugging in an auxiliary antenna for the best reception.

DUAL SPEAKER PLAY

Note: To enjoy Dual Speaker Play, you must have 2 BlockParty Bluetooth Speakers.

1. Ensure both speakers are powered on.
2. Ensure neither speaker is connected to your phone or Bluetooth device.
3. Press & hold the M button for 3 seconds to enter the dual speaker mode. The speakers will pair with each other automatically.
4. Connect to your phone or Bluetooth device to enjoy play from both speakers.

SPECIFICATIONS

Model	MyBat Pro BlockParty
Loudspeaker Output	7W
Horn Size	52mm
Bluetooth Version	5.3
Bluetooth Range	10~30m / 33~100ft
Frequency Response Range	120Hz - 20KHz
Signal Noise Rate	≥90DB
Battery Capacity/Voltage	1000mAh / 3.7V
Battery Charge Time	2H
Working Time	8H
USB Power Input	5V / 1A
Product Size	90x85x90mm
Product Weight	320g

SAFETY MEASURES

To ensure proper use of this product, please take the time to read this instruction manual carefully before use. Please observe all the instructions about safe operation and please keep this instruction manual in a safe place for future reference.

1. Protection of power supply wire: Do not place the cable in the path of foot traffic. Do not place heavy furniture on the cable. Never pull the cable to unplug the unit from the socket, always disconnect the unit from the main power supply by pulling the plug out of the socket.
2. Ventilation: In order to prevent this unit from overheating, place it in a well-ventilated area on a stable surface. Never place it on a bed, sofa or carpet where the ventilation will be restricted.
3. Dismantling: In order to avoid the risk of electric shock, do not dismantle the unit. Should your unit be faulty or broken please refer servicing to an authorized service center.
4. Strange Odor: Should the speaker emit any strange odor, immediately unplug it from the wall socket. Do not use the unit again until you have had it repaired or contacted the manufacturer.
5. Do not expose this unit to liquid of any kind.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

WARNING: Cancer and Reproductive Harm
www.P65Warnings.ca.gov
Made in China



www.mybatpro.com